

| NO | CODE | DESCRIPTION | Q'TY |
|----|----------------|-------------------------|------|
| 1 | ZCE140-1371 | Shell-Side Plate | 1 |
| 2 | ZCE140-1372 | Weldments | 1 |
| 3 | ZCE140-1373 | Body | 1 |
| 4 | ZCE140-1374 | Heater 360W | 2 |
| | ZCE140-1374-1 | Heater 300W | 5 |
| 5 | ZCE140-1375 | Inner-Left Partition | 1 |
| 6 | ZCE140-1376 | Inner-Left Side Plate | 1 |
| 7 | ZCE140-1377 | Transom | 2 |
| 8 | ZCE140-1378 | Projectile | 1 |
| 9 | ZCE140-1379 | Projectile Handle +Ball | 1 |
| 10 | ZCE140-13710 | Inner-Front Side Plate | 1 |
| 11 | ZCE140-13711 | Inner-Partition | 1 |
| 12 | ZCE140-13712 | Foot | 4 |
| 13 | ZCE140-13713 | Bottom Plate | 1 |
| 14 | ZCE140-13714 | Press Plate | 1 |
| 15 | ZCE140-13715 | Tray | 1 |
| 16 | ZCE140-13716 | Connecting Piece | 1 |
| 17 | ZCE140-13717 | Binding Post | 1 |
| 18 | ZCE140-13718 | Clip | 1 |
| 19 | ZCE140-13719 | Inner-Right Partition | 1 |
| 20 | ZCE140-13720 | Inner-Right Side Plate | 1 |
| 21 | ZCE140-13721 | Separated Mesh | 12 |
| 22 | ZCE140-13722 | Plate | 1 |
| 23 | ZCE140-13723 | Inner-Side Plate | 1 |
| 24 | ZCE140-13724 | Timer With Knob | 1 |
| 25 | ZCE140-13725 | Indicator Light | 1 |
| 26 | ZCE140-13726 | Switch | 1 |
| | ZCE140-137-A03 | Power Cord | 1 |